



AF106 Digital Automatic Fragrance Dispenser



Button Functions:

There are 9 Function buttons for the Fragrance Dispenser

1. **RESET** button: Use this button to remove previous set ups and applications
2. **SPRAY** (manual button): After putting batteries and a fragrance can into the unit, the spray button allows you to test that the unit is working correctly
3. **MODE** button: When pressing this button the LCD screen display will show the following options: Mode, Start, Stop, Spray, Interval, Week, Clock
4. **WEEK** button: use this to specify which week you would like the dispenser to work, there are 2 options available, Mon-Fri or Mon-Sun
5. **HOUR** button: use this button to specify at which time (hours) you would like the dispenser to spray
6. **MIN** button: Use this button to specify the minutes you would like the dispenser to spray
7. **ON/OFF** button
8. **LED light**: Green = ON, Red = OFF/ Replace fragrance can
9. **LCD Screen** displays battery life in left corner

Installation :

For maximum efficiency install Fragrance Dispenser approx. 2 meters off the ground and sit it on a stable, flat shelf or fix the dispenser to the wall.

Unit takes x2 D batteries

Avoid contact with eyes and Keep out of reach of children.

Set Up :

1. Insert x2 D batteries. For the initial set up of your fragrance dispenser begin by pressing the MODE button, the word "START" will appear on the screen
2. To set up the WORK CYCLE, press the MODE button until "WEEK" appears on the screen
3. There are 2 WEEK periods, which are from Mon - Fri or Mon - Sun, select the most appropriate for your needs
4. Set the Hour and the Minute (using the buttons provided) that you would like the dispenser to begin working (e.g. 9:23 or 16:45)
5. Press the MODE button again and the word "STOP" will appear on the screen
6. Set the Hour and the Minute (using buttons provided) that you would like the dispenser to cease working (e.g. 11:24 or 22:58)
7. To set the SPRAY INTERVALS, press MODE
8. The word INTERVALS should appear on the screen, use the MIN button to select the interval times from 1 - 60 min (e.g. If you select 5 intervals that means the dispenser will spray 5 times every 60 min)
9. To check how many times the dispenser has sprayed the fragrance, press MODE and the word "SPRAY" will appear on the screen with the number of times the dispenser has worked. On average 1 fragrance can will last approx. 3200 spray. When replacing the fragrance, make sure the dispenser is turned OFF

Fragrance Can installation :

1. Use the key provided to open the unit by pressing the round button on the top of the dispenser and open the cover
2. Insert fragrance can and close the dispenser
3. Turn the dispenser back ON and press the manual "SPRAY" button approx. 4 times to ensure the can has been installed correctly
4. 4. If necessary, reset your dispenser using the Set Up instructions

NOTE :

Please read the manual carefully before you use the dispenser.

